
How to change “Fan Motor Guide”

Please follow the below instructions to exchange the “Fan Motor Guide”

Step1: Detach the top cover of the chiller



Step2: Unscrew the 2 bolts on the upper side and bottom side of the “Fan Motor Guide”



Copyright 2022 by Kwangrim. No unauthorized reproduction. Last Published On Dec 2022

Step 3: Detach Fan Motor Cable lines U21, V21, and PE from the Terminal Block



Step 4. Unfasten the the cable ties



Copyright 2022 by Kwangrim. No unauthorized reproduction. Last Published On Dec 2022

Step 5: Move the “Fan Motor Guide” to the right side and remove it from the oil chiller.



Step 6: Assemble the new parts and reattach the “Fan Motor Guide” using the above steps in reverse order from when you detached the “Fan Motor Guide”



-E.O.D-

Copyright 2022 by Kwangrim. No unauthorized reproduction. Last Published On Dec 2022