How to release screen lock

- Symptom : Parameter screen is locked.
- Diagnose : You can find a dot '.'very last of the control board.
- Solution : Release the lock function

Step 1. Check if you have "." after temperature (Example. 16.7.)



Step 2. If you want to release screen lock, please push "Up" and "Down" button at once for about 3 seconds.



Step 2. Now screen is released and no you can see the "." is gone.



Copyright 2020 by Kwangrim. No unauthorized reproduction. Last Published On Apr.29 2020